

MACHINE MODELS

Tilt Cylinder Pin


Push Arm Pin

7 8 CAT D5N, D6, D7

SAFETY FIRST (1)

- 1. Wear Safety Equipment.
- 2. Keep hands and feet clear.
- 3. Beware of flying objects.

Prior to removing any pins or parts refer to Manufacturers Service manual for proper procedures for securing and stabilizing equipment.



See back for Pin Removal / Insertion specifications and recommended Slide Sledge® tool kit.



The following removal and insertion tips are manufacturer recommendations for this model. Other model track-type tractors may use similar tips and tools for similar removals. Consult with manufacturer for specific models and uses.

Item	Tool/Tip	Description	Part#
#1	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	7/8" Pin Driver	213102
#2	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103
#3	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103
#4	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103
#5	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103
#6	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103
#7	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103
#8	R/I Tool	13 lb./46" Slide Sledge	211203
	R/I Tip	1 1/4" Pin Driver	213103

Product	Part#		
13 lb./46" Slide Sledge	211203		
1 1/4" Pin Driver	213103		
7/8" Pin Driver	213102		
5 lb. Handle Weight	211808		

Recommended Tool Kit for Medium Track-Type Tractor

Removal and installation should only be performed on pins that have been properly serviced and maintained.